Inlet Filter Specifications:

Item #	Dimensions	Pieces per Carton	Pieces Per Pallet
IF1527X30C	1.5" x 27" x 30"	10 pads	120 pads
IF1527X21FTB	1.5" x 27" x 21'	1 roll	12 rolls
IF1527X75FTB	1.5" x 27" x 75'	N/A	3 rolls

Other pad and roll sizes are available upon request. Cartons sized to ship by UPS.

Inlet Filter Installation Instructions:



1. Remove sediment, debris, ice and snow from the inlet grate surface and surrounding area.

2. Verify fit by

inlet grate to ensure that Inlet Filter extends at least one inch beyond the front and both curb ends. The overlap slows water

drops into the inlet.



3. Position the mat. Place Inlet Filter on grate with the net side

and extending beyond the grate opening on the front and both sides. The zip ties attach Inlet Filter to the inlet grate cover WITHOUT LIFTING THE GRATE COVER.

4. Insert zip ties. Lift Inlet Filter slightly to enable you to see

Push the zip tie down through the Inlet Filter and loop under the grate bar. Insert the pointed end of the zip tie

Push the pointed end of the zip tie into the receiving end just enough to hold ends loosely. LEAVE ZIP TIES LOOSE UNTIL ALL TIES ARE LOOPED THROUGH THE MATS AROUND THE GRATES. Repeat Step 4 until all zip ties are installed loosely.



5. Tighten zip ties.

After attaching all of the zip ties, re-position Inlet Filter to completely cover and overlap the grate. Pull free end of zip-ties hand tight to anchor Inlet Filter to the grate. Cut off free end of zip ties to leave a 1" tail.



Inlet Filter is prepared for the next rain event.





Inlet Filter will collect a lot of sediment. Clean Inlet Filter while mounted on the grate, even if ponded water surrounds the inlet. This unique feature ensures all water entering the grate


of Inlet Filter to remove sediment and debris after each rain event.

1. Remove sediment from the

away from Inlet Filter.



2. Remove sediment from the f of Inlet Filter.





(317) 346-4110 www.drainagesolutionsinc.com

